



 NEWSKILL

# ANUKI

QUICK GUIDE

WIRELESS ANC EARBUDS

---





## OPERATION FUNCTION

Power on: light touch 5 seconds  
Power off: light touch 5 seconds  
Next song: Double touch the right earphone  
Previous song: Double touch the left earphone  
Volume up: Triple touch the right earphone  
Volume down: Triple touch the left earphone  
Answer the call: Light touch any side  
Reject the call: Light touch 2 second any side

## WARNING

1. Please do not take the earbuds apart and remodel. otherwise, it may cause electrical breakdown by the fire or even completely damage the product.
2. Please do not put the product under too high or too low temperature (Below 0°C or above 45°C).
3. Please avoid using the device indicator light near the eyes of children or animals.
4. Please do not use the device under thunderstorms. It may cause the device to malfunction and increase the risk of electric shock.
5. Please do not wipe the product with oil or other volatile liquids.
6. Please do not let the device get wet with liquids.

## NOTE

It may cause hearing damage under longtime using, please arrange the use time reasonably.



## CHARGING

### Earphone charging

When the earphone keeps flashing green light, it means battery low and will power off soon. Please put the earphones into the charge case, it automatically turn off and charging.

### Charge case charging

When the charge case keeps flashing green light, it means battery low. Please use the qualified charging cable provided by the manufacturer to charge. The red indicator light is always on during charging; After fully charged, the green indicator light is on for 10s then automatically goes out.

### Where to see the power display?

After the earphones have connected with the phone, there is a battery mark next to the blue-tooth or earphone symbol to display the battery level.



## DUAL EARPHONE MODE

### Method one

After fully charged, opening the cover, not need remove the ear-phones will turn on automatically, waiting about 5 seconds, the red and green lights flash, turn on Bluetooth on the phone, search for the pairing name "ANUKI" and click to connect.

### Method two

After fully charged, take the two earphones and touch about 5 seconds, the red and green lights flash, turn on Bluetooth on the phone, search for the pairing name "ANUKI" and click to connect.

## SINGLE EARPHONE MODE

After fully charged, take one earphone and touch about 5 seconds, the red and green lights flash, turn on Bluetooth on the phone, search for the pairing name "XG-5.0" and click to connect.



# HOW TO TURN ON NOISE REDUCTION / TRANSPARENCY MODE

## Transparent mode

When the headset is turned on or playing music, long press left and right about 2s on either side of the earphone, you hear a beep at the same time. Prompt tone to enter transparent mode, Prompt tone: transparency



## Noise reduction mode

In the transparent mode, long press either side of the left and right earphones about 2s, you hear a beep sound at the same time, Prompt tone: ANC on



## Turn off noise reduction / transparency mode

In the noise reduction mode, long press either side of the left or right for 2s, when you hear a beep, Prompt tone: ANC off

## Iphone support manual setting ANC mode



## How to set three modes by Iphone?






# RESET BLUETOOTH EARPHONE

Put the earphone into charging case to close. Take it out after 3-5s, it will automatically re-pair!

## ABOUT SIGNAL

1. Please notice the wearing method, do not cover the earphone by ear to prevent interruption of signal.
2. Do not cover any earbuds on the dual earbuds mode by hand, or it will result the interruption of signal.
3. Please use this earphone under its working range (10 meters) and for best results avoid obstacles in between the connected devices.
4. On the dual earbuds model, sometimes the connected of "R" maybe interrupted, please check the using condition or the working range.







 NEWSKILL

ANUKI

WIRELESS ANC EARBUDS