

NEWSKILL

PYROS

QUICK GUIDE

60% WIRED/WIRELESS RGB MECHANICAL GAMING KEYBOARD









Multi-functional Key Description

E.g.  = 1  +  = F1  +  = !


 + Esc ~	 + 7 F7	 + Y Prtsc	 + M End
 + 1 F1	 + 8 F8	 + U Scrk	 + , < Pgdn
 + 2 F2	 + 9 F9	 + I Pause	 + Enter Turn on/off arrow key function
 + 3 F3	 + 0 F10	 + H Insert	 +  Win Key Locking Control
 + 4 F4	 + _ F11	 + J Home	
 + 5 F5	 + =+ F12	 + K Pgup	
 + 6 F6	 + ← Del	 + N Del	

WinOS & MacOS Switch

  Switching to Windows Mode

  Switching to Mac Mode


Mac Multimedia Function in Mac Mode



1. Only in Mac mode, Win does not have this function.
2. The corresponding Mac multimedia function will only take effect if (F1-F12) is the first function.




BACKLIGHT MODE




Switch Backlight Mode


Switch cycle of 17 kinds of backlight modes





Switch Backlight Colour




Control the brightness of backlight


Press  to increase the brightness of backlight.

Press  to reduce the brightness of backlight to off.
There are four grades of backlight brightness and 1 grade to turn it off.



Control the speed of backlight

Press  to increase the speed of backlight.

Press  to reduce the speed of backlight to off. There are four grades of backlight speed.

Combination keys' function Switching and locking



Press Fn+Ctrl to switch to activating the second function of combination keys (except the arrow keys). Press Fn+Ctrl again, to restore the 9 keys main function Y/U/I/H/-J/K/N/M/,<, but the other combination keys still in the second function. Press Fn+Ctrl times, all the combination keys' main function recovery

Charging introduction

1. In order to ensure normal use, please charge before use.
2. Before charging: after plugging in the power, space key indicator light flashing 3 times and goes out.
After the full: the space key light flashes 5 times continuously and goes out.
Charging: If you unplug it, plug it in again, the space key light flashes 3 times continuously indicate not full, 5 consecutive flashes indicate full.
3. No operation for 3 minutes, keyboard in standby, wake-up keyboard only need to press any key.

Wired/Bluetooth mode introduction

Wired & Bluetooth Switch

1. The bottom switch in OFF mode, and the keyboard is in wired mode. Connect the data line and use it.
2. Bottom switch in ON state, keyboard in wireless module, the first use of wireless, must be paired before normal use.

Fn+Q/W/E short press: switch to corresponding Bluetooth

Long press: Bluetooth pairing

This product supports the storage of 3 Bluetooth devices at the same time, and can switch between 3 devices at will.

Bluetooth Connection method

1. Make sure that the switch on the back of the keyboard is "ON" (that is the keyboard is in Bluetooth mode).
2. Select a set of wireless modes to be connected through Fn+Q/W/E, such as Fn+Q
3. Press Fn+Q for 3 seconds, at which time the Q key flickers continuously and enters the Bluetooth matching mode.
4. Open the computer/mobile Bluetooth, search and connect the device.
5. Successful connection, Q key stop flickering, complete.

By analogy, repeating the above steps, Q/W/E can be stored in three wireless devices and switched