

NEWSKILL

SERIKE








QUICK GUIDE


RGB MECHANICAL KEYBOARD








BACKLIT MODES INTRODUCTION

1.  +INS: 5 Lighting modes switch
2.  +HOME: Breathing mode switch
3.  +PGUP: Colorful breathing modes switch
4.  +DEL: 10 flowing Lighting modes switch
5.  +PGDN: Side backlit switch
6.  +PAUSE: Monochrome backlight mode switch
7.  +ScrLK: Interactive dual lighting mode (available only in (1) backlight mode)

 + ↑ : Backlit brightness increasing, there are 6 grades of backlight brightness.

 + ↓ : Backlit brightness decreasing,
there are 6 grades of backlight brightness include 1 grade to turn it off.

 + → : Backlit movement speed increasing,
there are 6 grades of backlight movement speeds.

 + ← : Backlit movement speed decreasing,
there are 6 grades of backlight movement speeds.

NEWSKILL SERIKE RGB MECHANICAL KEYBOARD



CUSTOM BACKLIT SWITCHING

⌘ + F11: Custom backlit switch

Press ⌘ + 1! to enter the custom backlit mode storage → Press FN+F11 to activate the custom backlit recording, via which you can customize the backlit as needed.

→ Press ⌘ + F11 to store the recording when completed.

FN COMBINATION FUNCTION

⌘ + F1: my computer

⌘ + F2: Web browser

⌘ + F3: calculator

⌘ + F4: music player

⌘ + F5: last

⌘ + F6: start / pause

⌘ + left WIN: WIN key lock function

⌘ + F7: next

⌘ + F8: stop

⌘ + F9: magnifier

⌘ + F10: favorites

⌘ + F12: mailbox

The Caps, LED, Scroll, LED, Num, LED, and WIN LED are separate control units, both at the same time Indicator function.