CHRONDS TKL Quick guide

PROFESSIONAL RGB GAMING KEYBOARD



NEWSKILL CHRONOS TKL PROFESSIONAL RGB GAMING KEYBOARD



SPECIFICATIONS

System: Win7/ Win8/ Win10, iOS etc. Full keys anti-ghosting Switch working life: OUTEMU 50 million times Key number: 93keys ES layout Key stroke: 2.0±0.6mm Product interface: 2.0USB Cable: 1.8M braided cable with magnet ring, Gold plated USB Current consumption: >300mA Size: (L) 359mm x (W)141mm x (H) 37.2mm±0.3mm Weight: 850g±20g

FULL-SPEED TRANSMISSION RATE

SUPPORT CUSTOMIZED CUSTOMIZATION

WITH NUMBER PAD

RGB BACKLIT SUPPORT SOFTWARE

POWER OFF MEMORY



Fn combination keys E.g. 🗊 = F1 [🏝 + 🗊 = Media

🇞 + F1 Media	‰ + F7	Play/Pause	% + I	INSERT
🇞 + F2 Volume -	‰ + F8	Next	🗞 + К	END
🇞 + F3 Volume +	‰ + F9	Email	& +,	DEL
‰ + F4 Mute	‰ + F10	Home page	% + 0	PgUP
‰ + F5 Stop	% + F11	My Computer	% + L	PgDN
🗞 + F6 Previous	% + F12	Calculator	& +.	HOME

‰ + WIN_L

Lock/Open WINDOWS, The LED indicator in the upper right corner lights up/out.

& + W W S A D can be exchange to $\uparrow \downarrow \leftarrow \rightarrow$, the default is with normal function

% + 7

Numer lock function (When the NUM lock light is on, the 7 key light is white color ; when the NUM lock light is off, the 7 key light is synchronized with the backlight)



18 kinds of Backlight modes

🇞 + Impr	6 kinds of backlights	
🗞 + Inicio	6 kinds of backlights	
🗞 + Supr	6kinds of backlights	
→+ &	Change the backlight effect direction	
& +→	Change the backlit color	

+ &	↑ Increase backllight brightness(0%-20%-40%-60%-80%-100%)
+ 3	Decrease backlight brightness, total 6 levels(100%-80%-60%-40%-20%-0%)
*+ &	= Increase backlight speed, 5level
% + -	Decrease backlight speed
	backlight brightness set to the limit gear, all indicators blink for 3 times. backlight speed set to the limit gear, all indicators blink for 3 times

SNEWSKILL CHRONOS TKL PROFESSIONAL RGB GAMING KEYBOARD



Custom backlit recording and storage

Press Fn + `~ to enter the corresponding custom mode, then press Fn +`~ to enter the custom light recording state. and 5 indicator in the upper right corner are flashing, Click the button to record, press the keys you want to record first time, it would be in Red. Press twice, then it would be Orange; Press again, it would be Yellow ; Press fourth time, it would be Green, press again, then it would be Cyan; Press sixth time, it would be Blue; Press seventh time, it would be Purple; Press again, the keys would be in White, Press nighth times, then it would be colorless; Cycle. After recording, press FN+ `~ to save and exit. The first group is recorded and replaced.