



newskill

NIKK

PROFESSIONAL WIRELESS EARBUDS





PRODUCT DESCRIPTION

Version: Bluetooth V4.1

Charging method: Power supply with
output of DC5V 150mA

Battery type: Rechargeable lithium-ion polymer battery

Bluetooth power class: Class 2

Profile supported: HSP/HFP/A2DP/AVRCP/APT-X

Talk time: Up to 6.5 hours


Listen time: Up to 5 .5hours

Standby time: 240 hours

Play audio file from a mobile phone,
laptop or other Bluetooth device
connected with it. (AV dongle: General BT dongle)

Play audio files from a PC after connected with
its BT dongle, and also support wireless
internet voice chat through QQ, MSN and SKYPE.

PARING STEPS



PRESS AND HOLD 5s


NOTE:
The headset will power off automati-
cally 3 minutes without connection.

Under power-off status, press and hold
the MFB until the indicator light flashes
red and blue alternatively, then the
Headset enters the pairing mode;




Turn on Bluetooth on your mobile, find
the Model No. of the Headset, and
connect. Turn off Bluetooth of the first
mobile, and repeat the step above to
connect with the second mobile.

WEARING



Insert the ear bud, and rotate the headset to achieve an optimal fit.

TIPS ON CLIPS USAGE




Hold the cable with one clip



Hold the cable with two clips

IMPORTANT FEATURES


Last number redial



Power on - Press and hold the multifunction button (MFB) for 2s until the BLUE light flashes ;
Power off - Press and hold the MFB for 5s till the RED light on for 2s;

Call answer / end / reject

 Answer



Call answer - Answer by your phone or press the MFB, or say "yes"

 End



Call end - End by your phone or press the MFB;

 Reject



Call reject - Reject by your phone or press and hold the MFB for 2s, or say "no"

IMPORTANT FEATURES

Last nubmer redial / Play music / Track control / Volume adjust

 Last number redial



Last number redial - Quickly tap the MFB twice to redial the last dialed phone number;

 Play music



Play music - Press the MFB to play/pause music under music playing status;

 Track control



Track control - Press and hold the " Volume +" button for 2s to skip to the next song; Press and hold the " Volume -" button for 2s to play the previous song;

 Volume adjust




Volume adjust - Press the " Volume +" or " Volume -" button to increase or decrease the volume.

IMPORTANT FEATURES

Call answer / end / reject

 Reset the headset to factory settings



PRESS AND
HOLD 3s

Press and hold the volume "-" button for 3 seconds upon charging the Headset until the blue light flashes 3 times.

WARNING

- Use and keep the Headset under ambient temperatures;
- Don't throw it in case product damage caused;
- Don't disassemble, repair or alter the Headset;
- Don't clean the Headset with chemical solvent;
- Use a USB charger of DC5V to charge the Headset if necessary;
- Don't discard the Headset at random,
or put it into fire or high temperature environment (60 /140) in case of danger.

VOICE PROMPT

- You will hear "power on" when the Headset is powered on.
- You will hear "power off" when the Headset is powered off.
- You will hear "connected" when the Headset is paired.
- You will hear "low battery" when the Headset is in low power status.



 newskill

NIKK

PROFESSIONAL WIRELESS EARBUDS